

3UVIEW

Bus Rear Window LED Screen Installation Instruction



Contact Us:

ShenZhen 3u view CO., LTD

Address: Building B, Zhuoke Science and Technology Park, No. 190, Chongqing Road,
Fuhai Street, Baoan District, Shenzhen, Guangdong, China

Website: www.3uview.com

Catalog

<i>Bus Rear Window LED Screen</i>	1
<i>Installation Instruction</i>	1
Preparation After Receiving the Product	2
1. Installation Accessories	5
2. Installation tools	5
3. Installation steps	6
4. Precautions	9

Preparation After Receiving the Product


1. Prepare a 220V/110V to 24V transformer



2. Prepare an activated SIM card and insert it into the SIM card slot of the system card




3. Light up the LED screen through the transformer




3UVIEW


4. Download the LEDOK software to match the APN



5. Log in to the computer advertising publishing platform to check whether the LED screen is online normally



6. Upload and publish advertising content




3UVIEW

7. Install the LED screen on the vehicle








3UVIEW

1. Installation Accessories




1. Box bracket	Used to fix the screen, side window brackets are different
2. Box input power cord	3 core power supply cord
3. External power cord outside the box	3-core power supply line (with control line fuse)


2. Installation tools

				
Electric drill	Multimeter	Pliers	Ties	Phillips screwdriver

3. Installation steps




1. The LED car screen is installed at the rear of the car, horizontally centered and balanced up and down.




2. Keep a distance of at least **10CM** between the bus screen and the rear window. Prevent the screen body from shaking and breaking the vehicle rear window due to aging screws and loosening.



3UVIEW




3. The power control compartment needs to be drilled. When drilling the base hole with an electric drill, it can be slightly larger than the diameter of the screw. When opening a wire hole, make it slightly larger than the diameter of the power cord.



4. After the bracket is fixed on the base, Use 8 external hexagonal M8*70mm screws and washers to fix.



3UVIEW



[Click to enlarge for details](#)

5. Pass the power cord through the wire hole from top to bottom into the engine compartment and then reach the power control box. Connection method: The red power wire is connected to the positive output terminal of the main control box; the blue wire is connected to GND; the yellow-green wire trigger wire is connected to the key control terminal ACC.



6. After the installation is completed, check whether the wiring, power supply, and vehicle condition can work normally.

Turn on the power switch, turn on the key, and if the screen lights up normally, the installation is complete.

4. Precautions

1. Pay attention to keeping a safe distance from the engine when routing cables. You can use the cable tube when routing cables on the car.
2. Pay attention to the firmness of the wire ends when wiring, and the screws must be tightened.
3. The fixing screws between the bracket and the screen body must be tightened to prevent them from falling off due to vibration during vehicle operation, causing hidden dangers.
4. The antenna must be placed close to the glass. Remember not to hide it, which will affect the reception of signals.
5. To clean the rear window glass, you need to tear off the original static advertising paper and use alcohol or detergent to clean away the glue marks and dirt.
6. Check the hygiene on the car.
7. Check the engine for iron and wood chips left over from drilling.
8. Record the ID number and corresponding license plate number on the screen (to facilitate later maintenance and inspection, and to prepare for vehicle grouping in the future).